

# HOUSE OF KOLOR

## STANDARD SHIMRIN2 MIXING CHART

<p><b>KD3000</b> PRODUCTS NEEDED KD300 : KDA3000 : RU REDUCER</p>	<p><b>HIGH BUILD</b> <b>4 : 1</b> <i>KD</i> : <i>KDA3000</i></p>	<p><b>MEDIUM BUILD</b> <b>4 : 1 : 1</b> <i>KD</i> : <i>KDA3000</i> : <i>RU</i></p>	<p><b>SEALER</b> <b>4 : 1 : 2</b> <i>KD</i> : <i>KDA3000</i> : <i>RU</i></p>	<p>TIP : THE KD SERIES IS NOT A SUBSTITUTE FOR POLYESTER WHEN MIXED FOR A HIGH BUILD</p>
---	--	--	--	--

### S2 STANDARD BASE COATS

<p><b>S2 KARRIER BASE AND S2-FX PAC</b> PRODUCTS NEEDED S2-KARRIER BASE : S2-FX : RU REDUCER</p>	<p><b>STANDARD KARRIER MIX</b> <b>3 : 1</b> <i>S2-KARRIER BASE</i> : <i>S2-FX</i></p>	<p><b>RU MIX</b> <b>2 : 1</b> <i>STANDARD KARRIER MIX</i> : <i>RU</i></p>	<p>TIP : FOR FX ONLY WITH S2-00 USE "V" MIXING RATIO</p>
--	---	---	--

### S2 - KBC

<p><b>S2-KBC</b> PRODUCTS NEEDED S2-00 : KK : S2-FX</p>	<p><b>STANDARD KBC MIX</b> <b>8 : 1 : 1/2</b> <i>S2-00</i> : <i>KK</i> : <i>S2-FX</i></p>	<p><b>RU MIX</b> <b>2 : 1</b> <i>STANDARD KBC MIX</i> : <i>RU</i></p>	<p>TIP : FOR EVERY 3oz OF MIXTURE ADD 2 - 4oz OF KK</p>
---	---	---	---

### URETHANE KANDY

<p><b>UKK01</b> PRODUCTS NEEDED UKK01 : KU152 : RU REDUCER : KK</p>	<p><b>LOW SOLID</b> <b>4 : 1 : 2</b> <i>UKK01</i> : <i>KU152</i> : <i>RU</i></p>	<p><b>MEDIUM SOLID</b> <b>4 : 1 : 1</b> <i>UKK01</i> : <i>KU152</i> : <i>RU</i></p>	<p>TIP : FOR EVERY 32oz OF MIXTURE ADD 2 - 4oz OF KK</p>
---	--	---	--

### USC01 - SHOW KLEAR

<p><b>USC01</b> PRODUCTS NEEDED USC01 : KU152 : RU REDUCER</p>	<p><b>STANDARD USC01 MIX</b> <b>3 : 1 : 1</b> <i>USC01</i> : <i>KU152</i> : <i>RU</i></p>		<p>TIP : ALLOW EXTRA DRY TIME INBETWEEN COATS TILL HAND SLICK</p>
--	---	--	---